

Model Sounds Inc.

712-31 McEwen Avenue,
Ottawa, Ontario, Canada, K2B 5K6

ShockWave 3-5.1.2b Sound Module

Piper Senecall – One Engine Start on Two Sound Tracks

<u>Sound Clips</u>	<u>Description</u>
Sound Clip 1	NULL sound clip to start/stop Engine 1
Sound Clip 2	NULL sound clip to start/stop Engine 2
Engine1 Sounds	Piper Senecall engine sound set
Engine2 Sounds	Piper Senecall engine sound set

Use SOUND1 input to startup/shutdown Engine 1.

Use SOUND2 input to startup/shutdown Engine 2.

Use TH TTL1 input to control Engine1 sound speed.

Use TH TTL2 input to control Engine2 sound speed.